



PARTS

This switch has been modified to include one large alligator clip for the big battery cable terminal, and one small clip for the “S” terminal on the starter solenoid. As long as the battery master switch is on, and the remote starter switch button is depressed, the starter will operate with or without the ignition switch being on. It is intended only for intermittent use during troubleshooting.

